



Spare Parts List


LKIF In-Line Filter



SMS/DS



Clamp



SMS/DS

Pos.	Qty.	Description	1" Part No.	1.5" Part No.	2" Part No.	2.5" Part No.	3" Part No.	4" Part No.
1	1	Filter	9612-0250-01	9612-0250-02	9612-0250-03	9612-0250-04	9612-0250-05	9612-0250-06
5	1	Seal ring, EPDM (standard) ..	9612-0255-01	9612-0255-02	9612-0255-03	9612-0255-04	9612-0255-05	9612-0255-06
	1	Seal ring, NBR	9612-0255-07	9612-0255-08	9612-0255-09	9612-0255-10	9612-0255-11	9612-0255-12

Clamp

Pos.	Qty.	Description	1" Part No.	1.5" Part No.	2" Part No.	2.5" Part No.	3" Part No.	4" Part No.
1	1	Filter	9612-0249-01	9612-0249-02	9612-0249-03	9612-0249-04	9612-0249-05	9612-0249-06
2	1	Clamp ferrule	9612-0252-01	9612-0252-02	9612-0252-03	9612-0252-04	9612-0252-05	9612-0252-06
3	1	Seal ring, EPDM (standard) ..	9612-0254-01	9612-0254-02	9612-0254-03	9612-0254-04	9612-0254-05	9612-0254-06
	1	Seal ring, NBR	9612-0254-07	9612-0254-08	9612-0254-09	9612-0254-10	9612-0254-11	9612-0254-12
	1	Seal ring, PTFE	9612-0254-13	9612-0254-14	9612-0254-15	9612-0254-16	9612-0254-17	9612-0254-18
4	1	Clamp ring and screws	9611-31-1051	9611-31-1051	9611-31-1052	9611-31-1053	9611-31-1054	9611-31-1055
6	1	Seal ring, EPDM (standard) ..	9611-99-1358	9611-99-1359	9611-99-1360	9611-99-1361	9611-99-1362	9611-99-1363
	1	Seal ring, NBR	9611-99-0765	9611-99-0766	9611-99-0767	9611-99-0768	9611-99-0769	9611-99-0770
	1	Seal ring, PTFE	9611-99-1403	9611-99-1404	9611-99-1405	9611-99-1406	9611-99-1407	9611-99-1408
7	1	Clamp ISO ferrule	9611-31019-0	9611-31020-0	9611-31021-0	9611-31022-0	9611-31023-0	9611-31024-0
8	1	Support ring	9612-0477-01	9612-0477-02	9612-0477-03	9612-0477-04	9612-0477-05	9612-0477-06

Recommended Spare Parts: Pos. 3, 5 and 6

Alfa Laval

Alfa Laval
8201 104th Street
Pleasant Prairie, WI 53158-0909
Telephone: 800-558-2060
Fax: 262-947-4724
www.us.flow.alfalaval.com