



Spare Parts List

# LKTC Tank Leg





*AISI 304*

**Tank Leg with Base Plate**

<b>Pos.</b>	<b>Qty.</b>	<b>Description</b>	<b>0.75" Part No.</b>	<b>1" Part No.</b>	<b>1.5" Part No.</b>
		Tank Leg with Base Plate .....	9611710220	9611710230	9611710250
1	1	Nut .....	9611-71-035-0	9611-71-038-0	9611-71-041-0
2	1	Foot - solid .....	9611-71-036-0	9611-71-039-0	9611-71-042-0
3	1	Base plate .....	9611-71-037-0	9611-71-040-0	9611-71-043-0

**Tank Leg without Base Plate**

<b>Pos.</b>	<b>Qty.</b>	<b>Description</b>	<b>0.75" Part No.</b>	<b>1" Part No.</b>	<b>1.5" Part No.</b>
		Tank Leg without Base Plate .....	9611710290	9611710320	9611710320
1	1	Nut .....	9611-71-035-0	9611-71-038-0	9611-71-041-0
2	1	Foot - solid .....	9611-71-036-0	9611-71-039-0	9611-71-042-0

**Alfa Laval**

---

**Alfa Laval**  
8201 104th Street  
Pleasant Prairie, WI 53158-0909  
Telephone: 800-558-2060  
Fax: 262-947-4724  
[www.us.flow.alfalaval.com](http://www.us.flow.alfalaval.com)